

Pro-face Connect: LinkManager Version 11 Tutorial

Version 1.5 2024/02/16



Contents

Introduction	3
Requirements	
1 Connection to your GateManager	
2 LinkManager installation	
2.1 Additional Considerations: Web Proxy	
3 Connection to a Device	



Introduction

The objective of this document is to provide a step by step user tutorial to connect to a remote Device from the Proface Connect LinkManager Version 11.

Internal



Requirements

To be ready for this tutorial, you will need:

- A Customer Domain on GateManager (in this case Company-C)
- A Basic Administrator account (in this case Brian Smith)
- A remote device already configured with SiteManager Embedded
- A LinkManager License
- A SiteManager License with X agents, attached to the remote HMI.

Interna



1 Connection to your GateManager

- Go to LinkManager web page, i.e:
 - o https://jp.gatemanager.proface.com/lm
 - o https://us.gatemanager.proface.com/lm
 - o https://eu.gatemanager.proface.com/lm
- Select Certificate



- Upload your certificate by clicking on the "Choose File" button



Be careful to select a **LMC file** for your certificate.

For your information:

.lmc : LinkManager certificate .gmc : GateManager certificate






Accept the General Terms of Use.



After authentication, a similar screen should appear:




In this screen, you can notice the following information:

- 1- A LinkManager User (Brian Smith) is connected
- 2- Brian Smith belong to the domain "Company-C".
- 3- A device called "SP5500" is configured in this domain with a SiteManager.
- 4- The LinkManager interface is off.



2 LinkManager installation

In order to start the LinkManager, click on the below icon




You will be redirected to this window, click on "Start LinkManager".



On first usage, the GateManager will not find the LinkManager on your laptop, the following screen will appear:




Click on "Install/Update LinkManager" then a new window will appear with a link to download.





Download and run the LinkManager installer




<u>Note:</u> Once installed, the LinkManager software can be uninstalled through "Control Panel\Programs\Programs and Features" the same way other programs would be.

Close the windows, come back to the previous screen and click on "Start LinkManager".



A popup like this should appear:








Then approve that this account can use the LinkManager Client



The LinkManager status should pass by Detecting to Ready



Your LinkManager is now started and ready to be used.


Internal



2.1 Additional Considerations: Web Proxy

Note: If after all those steps, the LinkManager is still unable to be in "Ready" state, Click on this icon:

This window will appear, click on "Use Proxy"



And enter your Proxy settings then "Add & Go"




The LinkManager will be ready after those settings applied.

Ů LinkManager: Ready



3 Connection to a Device

Now you are able to connect remotely to your device:



- 1. Click on the device and select the agent
- 2. Click on Connect

Once connected, some information will appear about your connection as latency, bandwidth, heartbeat, uptime etc..

